ROCKVILLE

OWNER'S MANUAL

RPB-KAR

PORTABLE BLUETOOTH SPEAKER
w/MICROPHONE and TWS

Thank you for purchasing this Rockville RPB-KAR Large Portable Bluetooth Speaker with TWS. Please read this guide carefully. Should you need assistance, please call our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.

Included

- RPB-KAR Bluetooth Speaker
- 3.5mm to 3.5mm AUX Cable
- USB Charging Cable
- Carry strap
- Owner's Manual
- Warranty card

IMPORTANT SAFETY INSTRUCTIONS

- To reduce risk of electric shock, never open the unit. There are no user-serviceable parts, refer service to an authorized Rockville service center.
- Do not expose this unit to any kind of moisture.
- Please ensure that the unit is situated in a properly ventilated area.
- Make sure the unit is placed on a level and stable surface.

Functions

1. USB power input port
2. Micro SD port (file size limit: 32GB)
3. USB input (file size limit: 32GB) and DC 5V power output port
4. 3.5mm AUX input
5. ¼″ Mic input port
6. Rubberized protective cover
7. Hands free calling: Press to answer incoming call, press again to end call. Press and hold to reject call.
8. Previous/Volume -: short press to change track, long press to decrease volume.
9. Press and hold to turn the power on or off. When the unit is on, short press to turn the lights on/off and cycle though the LED modes.
   - Solid color (green/red/blue)
   - Color shift (blue/green/red)
   - Fast color shift (blue/green/red/light blue/yellow/purple)
   - Flash to the beat (cycles through all 6 colors)
10. Mode: Press to change modes (Bluetooth, USB, SD, AUX).
11. Next/Volume +: short press to change track, long press to increase volume.
12. Play/Pause
13. Battery status LED indicators



Bluetooth Pairing

1. Upon powering on, the speaker will automatically enter Bluetooth pairing mode.
   Please note: if the device is in another mode, press the Mode button to return to Bluetooth mode. Press this button for two seconds to disconnect current BT device and enter pairing mode.
2. Ensure your device is in Bluetooth mode and discoverable.
3. Under list of available devices search for and select RPB-KAR.
4. The unit will automatically connect to your device and you will hear the word connected.

ATTENTION: WHEN PAIRING YOUR BLUETOOTH DEVICE, PLEASE MAKE SURE THE VOLUME ON THE DEVICE IS TURNED UP.

Bluetooth Music

Long press the -/+ buttons to raise or lower the volume. Short press the -/+ buttons to navigate through tracks. Use the PLAY/PAUSE button to control playback.

Bluetooth Hands-Free

1. To answer or end a call press the button.
2. Press and hold the button reject an incoming call.

USB/SD Mode

1. Insert Micro SD card or USB flash drive (up to 32GB supported) into the corresponding port at the rear of the unit. Alternately, you can press the MODE button to select the desired input source.
2. Micro SD card/USB input should be automatically recognized and music will begin to play.
3. Long press the -/+ buttons to raise or lower the volume. Short press the -/+ buttons to navigate through tracks. Use the PLAY/PAUSE button to control playback.

Please note: Refer to Features and Specifications on page 5 for accepted file formats.

Aux Mode

1. Upon plugging in a 3.5mm jack, the unit will automatically switch to AUX input and begin to play music.

Please note: If you plug in the 3.5mm cable prior to turning the unit on, use the MODE button to select AUX mode.

2. Long press the -/+ buttons for to raise or lower the volume. Other playback functions can be con trolled from your device.

Charging

Charging the Unit

1. Plug the included micro USB cable into the micro port on the back of the unit.
2. While charging, the LED charging indicators will blink. When 3 of 5 LEDs are

blinking, the unit is 60% charged. When 4 of 5 LEDs are blinking, the unit is 80% charged. 5 solid red LEDs indicate that the speaker is fully charged.

3. Charge time is 4 hours.
4. During playback, if 4 of 5 LEDs are on, the unit is at 80% capacity. When 3 of 5 LEDs are on, the unit is at 60% capacity.

Power-bank Function

The USB port can be used to charge your phone or tablet.

Features and Specifications

- Larger size speaker for deep bass frequencies and very loud overall volume
- Built-in LEDs with 4 light modes
- Built-in USB power-bank to charge your phone or tablet
- RMS Power: 20W
- Uses high quality drivers and 2 passive radiator subwoofers to give amazing frequency range and sound quality.
- Uses DSP tuning along with top of the line drivers to achieve a very balanced sound
- Bluetooth 5.0 streams high fidelity audio and is highly efficient which increases battery life.
- Built-in SD card slot and USB playback (supports cards or sticks up to 32GB)
- Plays: MP3/WMA/APE/FLAC/WAV
- 3.5mm aux input
- Charge time: 4 Hours
- 7.4v/3000mAh lithium-ion battery supports up to 24 hours playback at 20% volume, 12 hours at 40% volume, and 4.5 hours at max volume
- Battery charges with included USB cable
- 5 LED battery life indicators
- Distortion: Less than 1%
- Frequency response: 45Hz – 20kHz
- Play, Pause, Skip Forward, Skip Back, Volume Up, Volume Down
- Will control next song, pause, play on popular apps like Pandora, Spotify, etc.
- 33 foot maximum Bluetooth range
- The built-in microphone allows you to make and receive phone calls hands-free
- Compatible with any Bluetooth devices such as iPad, iPhone, Laptops, Android phone, other cell phones, iPods, other Bluetooth MP3 Players.
- Built-in handle for easy portability
- Optional shoulder/neck strap for situations where you want to wear the speaker and be hands-free.
- Product dimensions: 11.57″ (L) x 4.25″ (W) x 3.54″ (H)
- Product weight: 3.85Lbs
- Color: Black

Troubleshooting

PROBLEM	SOLUTION
No Power	1. Make sure the unit is on. 2. Make sure the unit is charged. See page 4 for charging instructions.
Bluetooth pairing fails	1. Check to see that both devices are turned on and that your Bluetooth device is discoverable. 2. Make sure you've selected the proper source. 3. Make sure that the Bluetooth device is within 5 feet of the unit. 4. Check the speaker and input source volume settings. 5. Move both devices away from other Bluetooth devices, microwaves, wireless routers, and other electronics. 6. Make sure that the unit is not paired to a previously paired device. See the Bluetooth instructions on page 4.
No USB/SD playback	1. Make sure you've selected the proper source. 2. Check that the SD card or USB flash drive is not damaged. 3. Make sure that the SD card's or USB flash drive's capacity is no more than 32GB. 4. Make sure that the music files are in one of the following formats: MP3/WMA/APE/FLAC/WAV.

FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

Responsible party name: Rockville

Address: 600 Bayview Ave,
Entrance A,
Inwood, NY 11096

Hereby declares that the product Rockville RPB-KAR portable Bluetooth speaker complies with FCC rules as mentioned in the following paragraph:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ROCKVILLE

ROCKVILLE



RockvilleAudio.com

© 2020 ROCKVILLE // Features and specifications are subject to change and or improvement without notice.